

Autonics PANEL METER MT4N SERIES

M A N U A L



Thank you very much for selecting Autonics products.
For your safety, please read the following before using.

Caution for your safety

- Please keep these instructions and review them before using this unit.
- Please observe the cautions that follow:
 - Warning** Serious injury may result if instructions are not followed.
 - Caution** Product may be damaged, or injury may result if instructions are not followed.
- The following is an explanation of the symbols used in the operation manual.
 - Caution:** Injury or danger may occur under special conditions.


Warning

- In case of using this unit with machinery (Ex: nuclear power control, medical equipment, ship, vehicle, train, airplane, combustion apparatus, safety device, crime/disaster prevention equipment, etc) which may cause damages to human life or property, it is required to install fail-safe device. It may cause a fire, human injury or damage to property.
- It must be mounted on the panel. It may cause electric shock.
- Do not connect, inspect or repair terminals when it is power on. It may cause electric shock.
- Do not disassemble or modify this unit. Please contact us if it is required. It may cause a fire or electric shock.
- Please check the number of terminal when connecting power or measured input. It may cause a fire.


Caution

- This unit shall not be used outdoors. It might shorten the life cycle of the product or cause electric shock. Use this product indoors only. Do not use the product outdoors or at locations subject to the temperatures or humidity outside. (Example: rain, dirt, frost, sunlight, condensation, etc.)
- When connecting wire, AWG20(0.50mm²) should be used and tighten screw bolt with 0.74N·m to 0.90N·m strength. It may cause a malfunction or a fire due to contact failure.
- Please observe the rated specification. It might shorten the life cycle of the product and cause a fire.
- Do not use beyond of the rated switching capacity of relay contact. It may cause insulation failure, contact melt, contact failure, relay broken and fire etc.
5. In cleaning the unit, do not use water or an organic solvent. And use dry cloth. It may cause a fire and give an electric shock.
- Do not use this unit in place where flammable or explosive gas, humidity, direct ray of the light, radiant heat, vibration or impact, etc. exists. It may cause a fire or explosion.
- Do not inflow dust or wire drops into the unit. It may cause a fire or mechanical malfunction.
- Please wire properly after checking the polarity of measurement terminals. It may cause a fire or explosion.


Ordering information




Front panel identification




Panel cut-out



Terminal connection



Option



Prescale function [PA1: H-5C/L-5C]


This function is to display setting (1999 to 9999) of particular High/Low-limit value in order to display High/Low-limit value of measured input. If measured inputs are 'a' and 'b' and particular values are 'A' and 'B', it will display a=A, b=B as below graphs.

Error display function

Display	Description
HHHH	Flashes when measured input is exceeded the max. allowable input (110%)
LLLL	Flashes when measured input is exceeded the min. allowable input (-10%)
d-HH	Flashes when display input is exceeded H-5C setting value
d-LH	Flashes when display input is exceeded L-5C setting value
F-HH	Flashes when input frequency is exceeded the max. display value of measured range
oUr	Flashes when it exceeds zero range (±99)

※ Zero adjusting error is returning to measurement mode after [oUr] flashes twice.
※ Refer to "AC frequency measured function" for frequency measured range.

Initialization function



Display cycle delay function [PA2: d1 5L]

In some applications the measured input may fluctuate which in turn causes the display to fluctuate. By adjusting the display cycle delay function time at d1 5L of parameter 2, the operator can adjust the display time within a range of 0.1 sec to 5 sec. For example, if the operator sets the display cycle time to 4.0 sec, the display value displayed will be the average input value over 4 sec; and also will show any changes if any every 4 sec.

Startup compensation timer function [PA2: 5tR.L]

This time function limits the operation of an output until the measured input (overvoltage or inrush current) is stable at moment of power on. All outputs are off during startup compensation time setting after power is applied. Setting range: 0.0 to 99.9 (Unit: sec.) Factory default: 0.0

User manual for communication

Visit our website (www.autonics.com) to download the user manual for communication of MT series.
※ The above specifications are subject to change without notice.

Specifications

		MT4N	
Model	12-24 VDC/AC	100-240 VAC	
Power consumption	DC: 3W, AC: 5VA	5VA	
Display method	7 Segment LCD Display, Character height: 9mm		
Display accuracy	23°C ± 5°C: DC Type: F.S. ± 0.1% rdg ± 2digit / AC Type: F.S. ± 0.3% rdg ± 3digit -10°C to 50°C: DC/AC Type: Within F.S. ± 0.3% rdg ± 3digit only for Current 5A terminal -10°C to 50°C: DC/AC Type: F.S. ± 0.5% rdg ± 3digit		
Input specification	DC Voltage/Current, AC Voltage/Current, AC Frequency		
Max. allowable input	110% F.S. for each measured input range		
A/D conversion method	Practical oversampling using successive approximation ADC		
Sampling cycle	50ms (DC), 16.6ms (AC)		
Max. display range	-1999 to 9999 (4 Digit)		
Preset output	<ul style="list-style-type: none"> Relay output: Contact capacity: 125VAC 0.3A, 30VDC 1A/Contact composition: N (0/1a) NPN/PNP Open Collector output: 12-24VDC ± 2V 50mA Max. (Load resistance) 		
Sub output (Transmission output)	<ul style="list-style-type: none"> RS485 communication output Baud rate: 1200/2400/4800/9600, Communication method: 2-wire half duplex, Synchronous method: Sub-synchronization, Protocol: Modbus type DC4-20mA output: Resolution: 12,000 division (Load resistance max. 600Ω) 		
AC measurement function	Selectable RMS or AVG		
Frequency measurement function	Measurement range: 0.100 to 9999Hz (Differ according to decimal point position)		
Hold function**	Includes (Outer hold function)		
Insulation resistance	Min. 20MΩ (at 500VDC megger)		
Dielectric strength	1000VAC for 1 minute (Between external terminal and case)		2000VAC for 1 minute (Between external terminal and case)
Noise strength	± 2kV the square wave noise (pulse width: 1μs) by the noise simulator		
Vibration	<ul style="list-style-type: none"> Mechanical: 0.75mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each of X, Y, Z direction for 2 hours Malfunction: 0.5mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each of X, Y, Z direction for 10 minutes 		
Shock	<ul style="list-style-type: none"> Mechanical: 100m/s² (Approx. 10G) in X, Y, Z directions for 3 times Malfunction: 300m/s² (Approx. 30G) in X, Y, Z directions for 3 times 		
Environment	<ul style="list-style-type: none"> Ambient temperature: -10 to 50°C, Storage: -20 to 60°C Storage humidity: 35 to 85%RH, Storage: 35 to 85%RH 		
Insulation type	Double insulation or reinforced insulation (Dielectric strength between the measuring input part and the power part: 1kV)		
Approval	CE		
Unit weight	Approx. 64g		

※ 1: The indicator has no Hold function.
※ Environment resistance is rated at no freezing or condensation.

Specification of measured input and range [PA1: i-n-r]

Type	Measured input and range	Input impedance	Display range [Stnd]	Prescale Display range [5CRL]
DC Volt	0-50V [50V]	434.35kΩ	0.00 to 50.00 (Fixed)	0.0 -1999 to 9999
	0-10V [10V]	434.35kΩ	0.00 to 10.00 (Fixed)	0.0 -199.9 to 999.9
	0-5V [5V]	43.35kΩ	0.000 to 5.000 (Fixed)	0.000 -19.99 to 99.99
	0-1V [1V]	4.335kΩ	0.000 to 1.000 (Fixed)	0.000 -1.999 to 9.999
	0-250mV [250mV]	2.15kΩ	0.0 to 250.0 (Fixed)	0.00 -199.9 to 999.9
DC Ampere	0-500mA [500mA]	0.1Ω	0.0 to 500.0 (Fixed)	0.00 -199.9 to 999.9
	0-200mA [200mA]	0.1Ω	0.0 to 200.0 (Fixed)	0.000 -1.999 to 9.999
	0-50mA [50mA]	1.1Ω	0.0 to 50.00 (Fixed)	(Display range is variable according to decimal point position.)
	0-20mA [20mA]	1.1Ω	4.00 to 20.00 (Fixed)	
	0-5mA [5mA]	11.1Ω	0.000 to 5.000 (Fixed)	
AC Volt	0-250V [250V]	1.109MΩ	0.0 to 250.0 (Fixed)	
	0-125V [125V]	1.109MΩ	0.0 to 125.0 (Fixed)	
	0-50V [50V]	222MΩ	0.00 to 50.00 (Fixed)	
	0-25V [25V]	222MΩ	0.00 to 25.00 (Fixed)	
	0-5V [5V]	22MΩ	0.000 to 5.000 (Fixed)	
AC Ampere	0-2.5V [2.5V]	22MΩ	0.000 to 2.500 (Fixed)	
	0-5A [5A]	0.01Ω	0.000 to 5.000 (Fixed)	
	0-500mA [500mA]	0.1Ω	0.0 to 500.0 (Fixed)	
	0-250mA [250mA]	0.1Ω	0.0 to 250.0 (Fixed)	
	0-100mA [100mA]	0.5Ω	0.0 to 100.0 (Fixed)	

※ Please wire the proper terminal to its max. input within 30 to 100% of the input terminal. When it is higher than input, it may cause terminal breakdown and over display range. The accuracy is decreased when it is connected to the terminal under 30%.

Monitoring max./min. display value function [PA0: H.PEEL/PEL, PA2: PEEt]

It monitors max./min. value of display value based on the current display value and then displays the data at H.PEEL, PEL of parameter 0. Set the delay time (0 to 30 sec.) at PEEt of parameter 2 in order to prevent malfunction caused by initial overcurrent or overvoltage, when monitoring the peak value. Delay time is 0 to 30 sec. and it starts to monitor the peak value after the set time. When pressing any one of [MODE] keys at H.PEEL, PEL of parameter 0, the monitored data is initialized. ※ Monitoring function is not indicate when the delay time is set as "00 5" at PEEt of parameter 2.

Current output (DC4-20mA) Scale adjustment function [PA2: F5-H/F5-L]

It sets current output for the display value at the output current DC4-20mA. It sets display value for 4mA at F5-L and 20mA at F5-H and the range between F5-H and F5-L should be 10% F.S. (When it sets under 10% F.S., it changed as over 10% F.S. automatically.) Preset display value is fixed to output as 4mA at F5-L and 20mA at F5-H.

AC frequency measurement function [PA1: d1 SP]

It measures input signal frequency when it is AC input. It uses fixed decimal point (PA1: dot), measured range can be changed by setting and measured range of decimal point position is as below chart. It is available to adjust the upper gradient at [PA1: i-n-r] and [PA1: i-n-b]. In order to measure frequency normally, input signal over 10% F.S. of the measured range, should be supplied. Please select the proper point of measurement terminal.

Decimal point position	0.000	0.00	0.0	0
Measurement range	0.100 to 9.999Hz	0.10 to 9.99Hz	0.1 to 99.9Hz	1 to 9999Hz

※ Accuracy of frequency measurement: Below 1kHz, F.S. ± 0.1rdg ± 2digit. From 1kHz to 10kHz, F.S. ± 0.3rdg ± 2digit.

Error correction function [PA1: i-n-b/H/i-n-b/L]

It corrects display value error of measured input. i-n-b.L ± 99 (Adjust deviation of low value)
i-n-b.H: 5.000 to 0.100 (Correct gradient (% of high value))
Display value = (Measured value × i-n-b.H) + i-n-b.L
When the measured range is 0 to 500V, and the display range is 0 to 500.0, if the low display value is "12" to 0V input, set "12" as the i-n-b.L value to display "0.0" by adjusting the offset of the low value.
The display value to the 500V measured input varies by adjusting the offset of the low value. If this display value is "50 0", calculate 500.0/501.0 (the desired display value/the display value), and set the 0.998 correction value as the i-n-b.H to display "500.0" by adjusting the gradient of the high value.

※ The offset correction range of i-n-b.L is within -99 to +99 regardless of dot.

Zero adjustment function

It adjusts the display value of the optional configured input value as zero by force, zero point error can be adjusted with 3 ways as below.
When zero point adjustment with front key and Hold terminal is finished normally, zero point of measurement terminal is displayed and the adjusted value at saved in i-n-b.L automatically.

Operation	Input correction value	Front key	Input external signal
Des-cription	PA1: Direct input correction value method at i-n-b.L	Press both [MODE] keys for 3 sec. at the RUN mode.	Short-circuit external terminal No.11, 12 over min.50m. ※ It is enable to use in option mode.

※ Refer to description "Error correction function, Error display function, Error display function, Error display function" for function and error.

Gradient correction function [PA1: i-n-b.H]

It corrects the gradient of prescale value and display value. (Figure) [Display value] can be adjusted as α, β times against X input value by correction function [i-n-b.H] and used as correction function of max. display value [H-5C]. Adjustment range is 0.100 to 5.000 and multiply current gradient.

Setting method	H-5C	L-5C	i-n-b.H	Note
①	Unavailable	0.000	1.000	In this case, any setting methods display the same display value.
②	7.500	0.000	2.000	
③	5.000	0.000	3.000	
④	3.750	0.000	4.000	
⑤	3.000	0.000	5.000	

Preset output mode [PA2: oU1.L/oU2.L]

Mode	Output operation	Operation
oFF	OUT1 output	No output
Hi	OUT1.H OUT1 output	Period ON: Display value ≥ oU1.H Period OFF: Display value ≤ oU1.L + Hys
Lo	OUT1.L OUT1 output	Period ON: Display value ≤ oU1.L Period OFF: Display value ≥ oU1.L + Hys
HL	OUT1.H OUT1.L OUT1 output	Period ON: Display value ≤ oU1.L or Display value ≥ oU1.H Period OFF: Display value ≤ oU1.L + Hys or Display value ≥ oU1.H + Hys
HL-G	OUT1.L OUT1.H OUT1 output	Period ON: oU1.L ≤ Display value ≤ oU1.H + Hys Period OFF: Display value ≤ oU1.L + Hys or Display value ≥ oU1.H + Hys

※ Set output mode separately for each OUT1/OUT2.
※ OUT1/OUT2 are operated individually depending on output operation mode.
※ Setting value mode of parameter group 0 is displayed depending on output operation mode.
※ GO outputs when the period both OUT1/OUT2 are off (NPN/PNP Open collector output type)

Parameter

Parameter	Display	Function	Note
PR1 (Parameter 1)	i-n-r	Selectable RMS/AVG in AC type	Available AC type only.
	d1 SP	Selectable input range	Selectable: 5tnd/5CRL/Fr-E9
	Stnd	Selection of display type	Standard scale range of 5tnd
	Fr-E9	Frequency display	Available AC type only.
	SCrL	Scale range	These are displayed at 5CRL only. It sets max/min. display value (-999 to 9999).
	H-5C	Set max. value of display range	
	L-5C	Set min. value of display range	
	dot	Set decimal point position	It is displayed in 5CRL/Fr-E9 only and set the position.
	d-Unt	Display unit lamp	Set display unit.
	i-n-b.H	Input bias high	Correct High-limit gradient of display value
PR2 (Parameter 2)	i-n-b.L	Input bias low	Correct Low-limit gradient of display value
	i-n-b.E	Input bias exponent	Set display index of frequency mode
	oU1.L	OUT1 type	Selectable: oFF/Hi/Lo/HL/HL-G
	oU2.L	OUT2 type	Selectable: oFF/Hi/Lo/HL/HL-G
	Hys.1	OUT1 hysteresis	Select hysteresis of OUT1
	Hys.2	OUT2 hysteresis	Select hysteresis of OUT2
	5tR.L	Startup compensation time	Set startup compensation time
	PEEL	Peak time	Set monitoring delay time for peak value(sec)
	5L	Display time	Set sampling time(sec)
	CoLr	Color	Select color
PR0 (Parameter 0)	Er-o	Zero key	Set usage of front side zero adjustment key
	Ev-o	Event input	Set external terminal (11, 12) function
	FS-H	Full scale high	Set high-limit value output position of PV output.
	FS-L	Full scale low	Set low-limit value output position of PV output.
	Rd-5	Address	Set communication address
	bP5	Bit per second	Set baud rate (bps)
	P-ty	Parity bit	Set parity bit
	5tP	Stop bit	Set stop bit
	r5t	Response waiting time	Set response waiting time
	LoC	Lock	Enable lock status


Parameter setting

- Press [MODE] key for 2 sec. in RUN mode, [PR1] (Parameter 1) is displayed.
- Press [MODE] key for 4 sec. in RUN mode, [PR2] is displayed after [PR1]. When pressing [MODE] key continually, it stops displaying at [PR2].
- It is advanced to current display parameter releasing [MODE] key at [PR1] or [PR2]. Press [MODE] key for 3 sec. It is returned to RUN at any position.
- If any key is not touched for 60 sec. in each parameter, it returns to RUN mode.
- After return to RUN mode, press [MODE] key within 2 sec., it returns to previous parameter. (Refer to the below descriptions for set parameter.)


Change the parameter setting value

- Advance to the parameter to be changed when pressing [MODE] key continuously in RUN mode and releasing [MODE] key at the parameter. (Refer to "Parameter setting")
- When pressing [MODE] key in each parameter, the initial mode of the parameter is displayed. (Refer to the description of each parameter.)
- When pressing one of [MODE] keys in display mode, the saved setting value is displayed.
 - Ex) Mode: [MODE] value: [250u] The saved setting value flashes every 0.5 sec.
- Change the setting value by [MODE] or [MODE] key when setting value flashes.
 - Ex) Change AC type measured input from 250V to 125V.
- When confirming the setting value with [MODE] key, the changed setting value flashes twice and enters into the next setting.
- It returns RUN mode from parameter by pressing [MODE] key for 3 sec.

Parameter 1



Parameter 2



Caution for using

- Allowable installation environment
 - ① It shall be used indoor. (Pollution Degree 2)
 - ② Please use the terminal (M3.6, Max. 6.0mm) when connecting the AC power supply.
- Please use separated line from high voltage line or power line in order to avoid inductive noise.
- Please install power switch or circuit breaker in order to cut off the power supply.
- The switch or circuit breaker should be installed near by users for safety.
- Be sure to avoid using the following unit near by machinery making strong high frequency noise. (High frequency welder & Sewing machine, High capacity SCR unit, etc.)
- When input is applied, if "HHHH" or "LLLL" is displayed, there is some problem with measured input, please check the line after power off.
 - Noise inflowing from power line can cause serious problem for D.P.M. (Digital Panel Meter) driving by AC power supply. Even though there is condenser for protecting noise between lines in primary side of power transformer, but it is very difficult to install protection components at small size product like D.P.M. Therefore, please use noise absorber circuit such as line filter, varistor in external lines when voltage failure occurs by power relay, magnet SW and high frequency equipment are operated in same line or surge occurs by spark of high voltage or thunder etc.
- Input line: Shield wire that be used when the measuring input line is getting longer in the place occurring lots of noise.
 - Using line filter: Install it closely from D.P.M.
 - Using Varistor: Install it closely from D.P.M.
 - Using Double shield wire: Install it closely from D.P.M.
 - Using Single shield wire: Install it closely from D.P.M.
- It may cause malfunction if above instructions are not followed.

Main products

- Proximity sensors
- Area sensors
- Photoelectric sensors
- Fiber optic sensors
- Door/Door side sensors
- Rotary encoders
- Sensor controllers
- Tachometer/Pulse/Rate meters
- Temperature/Humidity transducers
- Switching power supplies
- Stepping motor/division motion controllers
- Field network devices
- Laser marking system (CO₂, Nd:YAG)
- Laser welding/soldering system
- Counters
- Timers
- Display units
- Panel meters
- Pressure sensors
- Power controllers
- Graphic Logic panels
- Temperature controllers

Autonics Corporation
Satisfiable Partner For Factory Automation

HEAD QUARTERS:
418, Yonggong-dong, Yongsan-gu, Gyeongnam, 628-847, Korea

AMERICA SALES:
1800, 4023 Park, Busheo Techno Park, 103, Yulsan-dong, Woomi-gu, Busheon-si, Gyeongbuk-si, 420-734, Korea
TEL: 82-52-612-7310 / FAX: 82-52-32-39728
E-MAIL: sales@autonics.com

The proposal of a product improvement and development. product@autonics.com

EP-KE-77-0012H